

Common Microsensor Types

- Thermal sensors measuring changes in temperature.
 Thermomechanical
 Thermoresistive
 - Thermocouples.
- Mechanical sensors properties of stain, force and displacement.
 - Piezoresistive strain in a semiconductor changes resistivity.
 Piezoelectric strain in a piezoelectric crystal causes a potential.
 - Piezoelectric strain in a piezoelectric crystal causes a pote
 Capacitive electrostatic, parallel plates and displacement.
 - Resonant microfabricated beams and bridges.
- Chemical sensors interaction with solids, liquids and gases.
- Radiant sensors ionizing radiation, and visible, infrared or UV light.
- Biosensors measurement of biological analytes (previous lecture).

even S. Saliterman

Shanbhag PP, Patil NS. BioMEM systems: A novel approach for drug targeting i diseases. New Horizons in Translational Medicine. 2017;3(6):265-271.





Piezoelectric Effects

- Transduction from mechanical to electrical domains and vice versa. May be used as sensors or actuators.
- A reversible and linear piezoelectric effect: • **Converse:** production of a <u>strain (stress)</u> upon application of an electric field.
- Direct: production of a <u>charge (voltage)</u> upon application of stress. • Three modes of operation depending on how the

res. Measur

ment Science & Tech

ogy 20, no. 9:0

- piezoelectric material is cut: transverse, longitudinal and shear.
- Amplifiers are needed to detect the small voltage. Tadigadapa, S., and K. Mateti. 2009. Piezoelectric MEMS sensors: state-of-the-art and pers





_

Piezoelectric Relationship...

• The piezoelectric effect is a linear phenomenon where deformation is proportional to an electric field:

Converse Effect Direct Effect S = dE *Where* D = dT

S is the mechanical strain,

d is the piezoelectric coefficient, E is the electric field,

D is the displacment (or charge density) linearly, and T is the stress.

Sensor Configurations... • Piezoelectric sensors maybe configured as direct mechanical transducers or as resonators. • The observed resonance frequency and amplitude are determined by the physical dimensions, material and mechanical and interfacial inputs to the device. Tadigadapa, S., and K. Mateti. 2009. P tric MEMS se

Approaches to Fabrication...

lapa, S., and K. Mateti. 2009. Pies

- Three approaches to realizing a piezoelectric MEMS devices:
 - Deposition of piezoelectric thin films on silicon substrates with appropriate insulating and conducting layers followed by surface or silicon bulk micromachining to realize the micromachined transducer ("additive approach").
 - Direct bulk micromachining of single crystal or polycrystalline piezoelectrics and piezoceramics ("subtractive approach").
 Integrate micromachined structures in silicon via bonding

electric MEMS sensors: state-of-the-art and p

 Integrate micromachined structures in silicon via bonding techniques onto bulk piezoelectric substrates ("integrative approach").

Piezoelectric Materials...

- Crystals

 Quart SiO₂
- Quart SiO₂
 Berlinite AIPO₄
- Gallium
- Orthophosphate GaPO₄
- Tourmaline (complex chemical structure)
- 2. Ceramics
 - Barium titanate BaTiO₃
 - Lead zirconate titanate PZT, Pb [ZrxTi1-x] O3 ; x = 0,52
 - Other Materials • Zinc oxide ZnO
 - Aluminum nitride AIN
 - Polyvinylidene fluoride PVDF

teven S. Saliterman



Thermosensor Basics

- Platinum resistor:
 - Linear, stable, reproducible.
 - Material property dependency on temperature,
- Thermocouples (e.g. Type K)
- Thermistor: a semiconductor device made of materials whose resistance varies as a function of temperature.
- Thermodiode and Thermotransistor.

Steven S. Saliterma





Microforce Measurement

• Microforce sensing considerations:

- Contact force feedback is essential for microassembly.
- Forces may be in the micro-newton range.
- Micromanipulation (handling micro-scale objects) e.g. cells or capillaries.
- Other micro-components are easily destroyed e.g. microgrippers.
- Alignment of micro-optical systems.

Wei YZ, Xu QS. An overview of micro-force sensing tech Actuators a-Physical. 2015;234:359-374.

Wei YZ, Xu QS. An overview of micro-force Actuators a-Physical. 2015;234:359-374.

Methods...

- Force sensing methods (examples to follow): Strain gauge-based force sensor.
 - Piezoresistive force sensor.
 - Capacitive force sensor.
- Piezomagnetic force sensor. • Others

 - Optical force sensor (Raman spectrometer, laser interferometer, AFM, optical tweezers).
 - Vision-based force sensor.
 - Electroactive force sensor (electronic and ionic).
 - PZT force sensor (based on direct piezoelectric effect).
 PVDF force sensor (polyvinylidene difluoride).

































Flow Sensors

- Measurement of gas and liquid flow rates.
- May be integrated with microfluidics.
- Useful for blood and urine flow, respiratory monitoring and drug delivery devices.
- Advantages of high sensitivity, accuracy and precision, low power consumption and small size.
- Broadly categorized as thermal (thermal exchange) and non-thermal flow sensors.

Steven S. Saliterman

Thermal Flow Sensing...

1. Hot wire or hot element anemometers.

- Based on convective heat exchange taking place when the fluid flow passes over the sensing element (hot body).
- Operate in constant temperature mode or in constant current mode.
- 2. Calorimetric sensors.
 - Based on the monitoring of the asymmetry of temperature profile around the hot body which is modulated by the fluid flow.

Steven S. Saliterm



• In a steady state, the mass flow rate can be determined:

$$Q_m = \frac{dm}{dt} = \frac{P_h}{c_m} (T_2 - T_1)$$

Where Q_m is the mass flow rate, P_h is the heat transferred per unit time,

- c_m is the specific heat capacity of the fluid and
- T_1, T_2 are temperature.

Steven S. Saliterman

• The volumetric flow rate is calculated as follows:

$$Q_V = \frac{dV}{dt} = \frac{Q_m}{\rho_m}$$

Where Q_V is the volumetric flow rate, Q_m is the mass flow rate and ρ_m is the density.

Steven S. Saliterm











Non-Thermal Flow Sensors

- Cantilever type flow sensors

 Measuring the drag-force on a cantilever beam.

 Differential pressure-based flow sensors

 When a fluid flow passes through a duct, or over a surface, it produces a pressure drop depending on the mean velocity of the fluid.

 Electromagnetic

 Laser Doppler flowmeter
 The phenomenon is due to the interaction between an electromagnetic or acoustic wave and a moving object the wave is reflected back showing a frequency different from the incident one.
 Lift-force and drag flow sensors

 Based on the force acting on a body located in a fluid flow.

 Neating turbine
 Resonating flow sensors

 Temperature effects resonance frequency of a vibrating membrane.
 Temperature effects resonance frequency of a vibrating membrane.

Silvestri, S. and E. Schena Micromachined Flow Sensors in Biomedical Applications. Micromachines 2012, 3, 225-243





Summary

- Sensors
 - Microsensors types. Wheatstone bridge operation. Piezoelectric effects.
- Thermosensors
- Micro force sensor examples:
- Strain gauge-based force sensor.
 Piezoresistive force sensor.

- Capacitive force sensor.
 Piezomagnetic force sensor.
 Flow sensors Thermal and nonthermal.
- Appendix Sensor classification & modeling a piezoelectric sensor.

Sensor Classification Schemes

- A sensor measures information from the environment (e.g. a blood analyte, or measurand) and provides an electrical signal in response.
- Sensors may be classified in various ways:

 - Sensors may be classified in various ways:
 Measurand temperature, pressure, flow etc.
 Transduction (physical and chemical effects) SAW, ion selective FETs, optodes (chemical transducer) etc.
 Materials resistive, piezoelectric, magnetic, permeable membranes, etc.
 Technology MEMS, bioMEMS, plasmon resonance, CMOS imaging, charge coupled devices etc.
 Energy requirement active or passive.
 Applications industrial, automative, aviation, consumer electronics, biomedical etc.









- A piezoelectric sensor can be modeled as a charge source Q_T with a shunt capacitor C_T and resistor R_T or as a voltage source with a series capacitor and resistor.
- The charge produced depends on the piezoelectric constant of the device and the input mechanical signals.
- The capacitance is determined by the area, the width and the dielectric constant of the piezoelectric material.
- The resistance accounts for the dissipation of static charge through leakage.
- Operational amplifier-based circuits can be readily used for amplification of piezoelectric sensors. The voltage amplifier circuit shown in top figure is typically used when the amplifier circuit can be located very close to the transducer and when the effect of the parasitic capacitance C_p can be minimized in the performance of this circuit. The resistor R_g is typically very large and provides the required biasing for the input stage of the circuit.
- The charge amplifier circuit is based on the Miller integrator circuit is shown in the bottom figure. The feedback resistor R_F is required to prevent the circuit from saturating due to the charge build-up on the capacitor C_F. In this circuit, the amplifier keeps the two input terminals at the same voltage, and therefore the parasitic capacitance does not affect this circuit.



